



# WARM AIR HEATING CONTROLS




V5306




V5307




386449-1




S8610



S87- S860



V404



V804




VS824

**Parts for V400 & V800 Gas Valves**

V5306B 1009 Pressure Regulator	Each	1
V5307B 1156 2 Stage Regulator	Each	1
V5307B 1214 2 Stage Regulator	Each	1
V5307A 1216 2 Stage Regulator	Each	1
VS824B 1009 Operator - Pwrpile	Each	1
V404B 1021 Operator - 120 Volt	Each	1
V804B 1022 Operator - 24 Volt	Each	1
#391937 L.P. Conversion Kit	Each	1
#392394B Power Unit - Pwrpile	Each	1
#392782 Nat To L.P. Blank Plate	Each	1
#394073 V800 Valve Knob&Shroud	Each	1
#386449-1 1/4" Pilot Nut & Ferrule	Each	1

**Parts for V8289 & VS8289 Gas Valves**

V5108A 1019 Pressure Regulator	Each	1
V8254A 1023 24 Volt Operator	Each	1
VS8002A 1055 Pwrpile Operator	Each	1
#391477B Pwrpile Power Unit	Each	1
#391479B Pwrpile Power Unit	Each	1
V8294A 1017 24V Operator-V8202	Each	1



Y86

**HONEYWELL ELECTRIC IGNITION KITS**

Y86H 3006 Ignition Control 1/2 x 3/4 Nat.Gas - 100% Shut Off	Each	1
Y86F 3018 Ignition Control 3/4 x 3/4 Nat.Gas Non 100% Shut Off	Each	1

**HONEYWELL ELECTRIC IGNITION MODULES**

S8670D 1000 Intermittent Pilot Spark Ignitor - 45 Sec Prepurge 90 Sec Lockout For Use With Combination Igniter Sensor	Each	1
S8610U 1003 Univ. Intermittent Pilot Spark Ignitor - 90 Sec Lockout For Combination Igniter Sensor or Separate Igniter and Sensor	Each	1

**HONEYWELL ELECTRIC IGNITION ACCESSORIES**

Q347A 1004 Spark Ignitor	Each	1
Q354A 1018 6" Flame Rectification Sensor	Each	1
392125-1 Ign.Cable(25")For Y86	Each	1
392431 Electrode For Y86	Each	1

392431  
ELECTRODE




392125 CABLE



Q354A 1018 FLAME SENSOR

**HONEYWELL ELECTRIC IGNITION PILOT BURNERS**

Q345A 1305 EI Pilot Burner	Each	1
Q345A 1313 EI Pilot Burner	Each	1
Q345A 1321 EI Pilot Burner	Each	1



Q345

