



WARM AIR HEATING CONTROLS




Q308



Q314




Q327



Q340



S688



S830

HONEYWELL STANDING PILOT BURNERS

DESCRIPTION	Unit	Qty.	Price
Q327A 1626 Pilot Burner	Each	1	
Q314A 3547 Pilot Burner	Each	1	
Q314A 4586 Pilot Burner	Each	1	
Q314A 6094 Pilot Burner	Each	1	
Q314A 6102 Pilot Burner	Each	1	

HONEYWELL THERMOCOUPLES

Q340A 1066 18" Thermocouple	Each	1	
	Ctn.	10	
Q340A 1074 24" Thermocouple	Each	1	
	Ctn.	10	
Q340A 1082 30" Thermocouple	Each	1	
	Ctn.	10	
Q340A 1090 36" Thermocouple	Each	1	
	Ctn.	10	
Q340A 1108 48" Thermocouple	Each	1	
	Ctn.	10	

PILOT BURNER FLAME PATTERNS

Q308A1881



Q314A3547



Q314A4586



Q314A6094



Q314A6102




Thermo-
couple



Main
burner
ignition
flame
1 in.
span
Q327A 1626

■ DENOTES
THERMOCOUPLE


Q345A1305




Q345A1313




Q345A1321




Q314 A MOUNTING



Q314 B MOUNTING




Q308A MOUNTING




THERMOCOUPLE ADAPTERS

#390012C Female Adapter	Each	1	20.40
Q357A 1003 Thermocouple Adapt.	Each	1	9.12
#392451-1 Thermocouple Adapt.	Each	1	24.50

390012C



392451



Q357

